Thanks for purchasing the PHANTOM Digital Mini Scale! This User Guide is designed to get you up and running quickly with your scale. Scales are precision instruments and require proper care and skill to get the best results. If you have questions or need support, visit us at http://www.obscales.com/support or scan the QR Code on the back of this manual using your smartphone.

What's In The Box

User Guide

Two AAA Batteries Plastic Cover / Weighing Trays

PHANTOM Digital Mini Scale










Key Descriptions

ON/OFF - Press to turn the scale ON or OFF. **TARE** - Zero's the scale.

Also subtracts the weight of an empty container or tray (see


Tare Function).



C/M: CAL/MODE - Tap to change the weighing unit. Hold for 3 sec. to enter Calibration(see Calibration). Hold for 4 sec. to temporarily disable the auto-off function.

Weighing Your First Item

- 1. Press the **ON/OFF** key to turn the scale on.
- 2. Place the item on the centre of the weighing platform.
- 3. The display will show & when the weight is stable.
- Take your reading from the 4. display. You can press the C/M kev to convert between weighing units.
- The scale's auto-off function 5 will turn the scale off after 3 minutes of inactivity or you



Things To Avoid



Unlevel Surfaces



Radio Frequency Interference



High Humidity



Air Currents



Vibration



Extreme Temps

Tare Function

The Tare function allows you to subtract the weight of a container so that the display only shows the weight of the contents.



Place an empty tray or container on the platform.

Press the **TARE** key to subtract the container's weight.

Add items to the container to see their weight on the display.



NOTE: The weight of the container will subtract from the available capacity and will leave a negative value on the display once the weight is removed. Press **TARE** again to return the display to zero.

Accuracy

Your scale comes calibrated from the factory and most users wont need to calibrate their scale for a long time. You should check your scale's accuracy periodically using calibration weights and perform calibration if necessary.



NOTE: Only use trusted calibration weights. Household items such as bottles and cans with weights printed on the side are not suitable for checking accuracy as these values are approximate and don't include the container weight (Net Weight).

Calibration

Our scales ship pre-calibrated and ready to weigh. You should periodically check accuracy using calibration weights and perform a calibration adjustment if necessary. Calibration is permanent and should only be performed using accurate calibration weights that match the requirements for your scale (see the chart on back). Do not use coins or other household items to calibrate.

- Prepare the required weight for your scale. (see chart on back)
- Find a flat and level surface to perform calibration and let the scale adjust to room temperature.
- Press ON/OFF to turn the scale on and wait for the scale to stabilise.
- 4. Make sure nothing is on the platform then press and hold the **C/M** key until the display shows 'CAL'.
- The display will then flash the required calibration weight.
- Place the required calibration weight on the centre of the platform.
- The display will show 'PASS' then return to normal weighing mode. You may now turn the scale off or continue weighing.



Specifications

	PH-200
Max Capacity	200 g / 7.055 oz / 6.430 ozt/ 128.60 dwt / 1000.00 ct / 3086.4 gn
Readability	0.01 g / 0.001 oz / 0.001 ozt / 0.01 dwt / 0.05 ct / 0.2 gn
Weighing Units	g, oz, ozt, dwt, ct, gn
Dimensions	Overall: 75 mm x 95 mm x 16 mm Platform: 75 mm x 95 mm Display: 15 mm x 33 mm
Calibration Weight	200g
Power	2 x AAA Batteries
Warranty	10 Year Limited Warranty

